

## B 35 CED

| Poz  | Code     | Nazwa                  |
|------|----------|------------------------|
| 1    | 4110.130 | Handle                 |
| 2    | 4110.121 | Upper Shell            |
| 3    | 4109.590 | Screw/Lockwasher, 1/2" |
| 4    | 4110.115 | Combustion Chamber     |
| 5    | 4100.671 | Heat Shield            |
| 6    | 4160.602 | Screw, #10-16 x 3/4"   |
| 7    | 4100.658 | Photocell Bracket      |
| 8    | 4103.529 | Screw, #6-32 x 3/8"    |
| 9    | 4110.564 | Photocell Assembly     |
| 10   | 4110.563 | Power Cord             |
| 12   | 4105.287 | Power Line RFI Filter  |
| 13   | 4101.151 | Bushing                |
| 14   | 4150.528 | Strain Relief Bushing  |
| 15   | 4100.662 | Fan                    |
| 16   | 4150.553 | Rubber Bumper          |
| 17   | 4110.187 | Motor Bracket          |
| 19   | 4103.685 | Fan Guard              |
| 20   | 4108.486 | Hex locknut            |
| 21   | 4101.152 | Bushing (wires)        |
| 22   | 4110.124 | Screw/Lockwasher, 1/2" |
| 23   | 4110.535 | Lower Shell            |
| 24   | 4104.170 | Clip Nut               |
| 25   | 4110.133 | Screw, #10-32 x 3/4"   |
| 26   | 4104.147 | Rubber Airline         |
| 27   | 4109.567 | Fuel Line              |
| 28   | 4110.195 | Wire Assembly (red)    |
| 29   | 4100.541 | Rubber Bushing         |
| 30   | 4110.135 | Fuel Filter Assembly   |
| 31   | 4110.609 | Electronic Ignitor     |
| 32   | 4108.510 | Screw, #10-16 x 3/4"   |
| 33   | 4106.110 | Terminal Board         |
| 34   | 4110.571 | Rivet                  |
| 35   | 4104.196 | Flame-Out Control      |
| 36   | 4103.891 | Fuel Tank Cap          |
| 37   | 4110.136 | Fuel Tank              |
| 38   | 4104.175 | Side Cover             |
| 39   | 4110.134 | Nut, #10-32            |
| 40   | 4109.592 | Hex Nut                |
| 41   | 4101.151 | Bushing                |
| 42   | 4110.075 | Vinyl Foam Gasket      |
| 43   | 4160.613 | Lock Washer, #10       |
| 44   | 4110.165 | Wire Assembly (black)  |
| 45   | 4106.179 | ON/OFF Switch          |
| 46   | 4104.336 | Switch Cover           |
| 11-1 | 4110.092 | Bracket                |
| 11-2 | 4109.526 | Spark Plug             |

| Poz       | Code     | Nazwa                     |
|-----------|----------|---------------------------|
| 11-3      | 4100.664 | Nozzle Adapter            |
| 11-4      | 4109.518 | Nut, 14mm                 |
| 11-5      | 4100.648 | Nozzle                    |
| 18-1      | 4110.042 | Motor (230V/50Hz)         |
| 18-2      | 4101.532 | Pump Body                 |
| 18-3      | 4108.635 | Insert                    |
| 18-4      | 4103.441 | Rotor                     |
| 18-5      | 4109.724 | End Pump Cover            |
| 18-6      | 4109.716 | Lint Filter               |
| 18-7      | 4109.690 | Intake Filter             |
| 18-8      | 4109.674 | End Cover                 |
| 18-9      | 4108.528 | Screw, #10-32 x 1"        |
| 18-10     | 4108.379 | Steel Ball (1/4" Dia.)    |
| 18-11     | 4102.141 | Pressure Relief Spring    |
| 18-12     | 4102.133 | Adjusting Screw           |
| 18-13     | 4102.125 | Plug                      |
| 18-14     | 4109.708 | Output Filter             |
| 18-15     | 4108.536 | Screw, #10-32 x 1 1/8"    |
| 18-16     | 4100.661 | Elbow, 90° (Barb Fitting) |
| 18-17     | 4101.666 | Blade                     |
| 18-18     | 4108.590 | Screw, #10-32 x 3/4"      |
| not shown | 4105.292 | Filler Neck Screen        |
| not shown | 4100.426 | Room Thermostat TH 2      |
| not shown | 4109.427 | Pressure Gauge            |